



Remarks:

1. After the Loading Screw (item #13 on the drawing) is set to the desired level, apply a little silicone to the Load Screw from underneath to keep it tight.
2. Remove Lock Plate (item #10 on the drawing) after installation.
3. Two Positioning Bolts (item #7 on the drawing) shall be in the top plate's two holes. After being fastened, these bolts shall be 3 mm below the surface of the top plate but not touch the top plate.
4. Recommended tighten torque for load cell is 90 to 110Nm.

15	Shield			1	
14	Spacer			1	
13	Loading Screw			1	
12	Loading Pin			1	
11	Cap			1	
10	Lock plate			1	
9	Fastern bolt	M6X10		4	
8	Nut	M12X35		2	
7	Positioning bolt	M12X65		2	
6	Top plate			1	
5	Shield fastern bolt	M6X10		2	
4	Load cell fastern bolt	M12X55		2	
3	Washer	Ø12		2	
2	Load Cell			1	563YS
1	Base plate			1	
ITEM	DESCRIPTION	MATERIAL	SPECIFICATION	QTY	REMARKS

V0	APPROVED	Alex. T	DATE	88-88-88
CHECKED	Allen. Z	DATE	15-07-01	
DRAWN	Felix. Z	DATE	15-07-01	

ANYLOAD

TITLE:

563YSM3-(500-SE5000) 1b
General Arrangement

DRAWING NO. : LM1506006

PROJECTION: SHEET 1 OF 1

IMPORTANT NOTICE

This document consisting confidential proprietary information belongs to ANYLOAD who retains all copy and other rights. This document is submitted under a confidential relationship for specific purpose, and the recipient agrees by accepting this document not to supply or disclose any information regarding it to any unauthorized person.